


Combination Shower Hand Operate (C.H.)



Instructions for Handling Safety Shower and Eyewash Unit

- Connect potable or clean water supply to shower or eyewash unit.
- Keep the over head water storage tank clean and closed
- Eyewash and safety shower unit should get 2.5 kg - 3kg pressurized water.
- Provide stainer before shower connection to provide clean water.
- Avoid multiple connections from one small tank.
- Repair minor leakages or defects.
- Keep regular maintenance of Eyewash and Safety Shower.
- Test Eyewash and Safety Shower regularly.

